

A500003

Tank Installation Instructions

RAPTAIR60 Diesel Driven Compressor

Important Information

The information in this manual is intended for certified VMAC installers who have been trained in installation procedures and for people with mechanical trade certification who have the tools and equipment to properly and safely perform the installation. Do not attempt this installation if you do not have the appropriate mechanical training, knowledge and experience.

Follow all safety precautions for mechanical work. If you have difficulty with the installation, contact VMAC.

To order parts, contact your VMAC dealer. Your dealer will ask for the VMAC serial number, part number, description and quantity. To locate your nearest dealer, call 1-800-738-8622.

Notice: Manuals and products are subject to change without notice

Document #1900918

Version	Revision Details	Revised by/date	Approved	Implemented
A	Release	SH 13 Sep2011	SM 13 Sep 2011	13 Sep 2011

Copyright 2011

All trademarks used in this manual are the property of the respective copyright holder. The contents of this manual may not be reproduced in any form without the express written permission of VMAC, 1333 Kipp Road, Nanaimo, BC V9X 1R3.

Printed in Canada

VMAC – Vehicle Mounted Air Compressors
Toll Free: 1-800-738-8622 Local: 1-250-740-3200
Fax: 1-250-740-3201

Fuel Tank Installation

1. The fuel tank will be installed on the rear (right hand side of the service panel) of the RAPTAIR60 using four existing mount bolts and one supplied bolt.
2. Remove the two M8 flange head bolts on the rear upper left and right hand corners
3. Loosen, but do not remove the two lower vertical separator tank mount bolts. You will need approximately $\frac{1}{4}$ " to slide the fuel tank into place.
4. Slide the fuel tank into place. Fasten with previously removed and supplied fasteners. Note the supplied M8 flange head bolt will be installed from the bottom up, with the supplied M8 flange head nut on the inside of the RAPTAIR60.
5. Connect supply and return fuel lines from the RAPTAIR60 to the fuel tank using supplied hose clamps. The supply line is $\frac{5}{16}$ " and the return line is $\frac{3}{16}$ "
6. Connect the fuel level sensor to the RAPTAIR60 harness.

